


SKIP*HOP®

9N390710-03
9N861210-03
9P088810-03

wooden activity gym



OWNER'S MANUAL

© Skip Hop, Inc.

SKIP HOP and MUST-HAVES MADE BETTER are trademarks owned by Skip Hop, Inc. All rights reserved.


100 W 33 ST, STE 1125, NY, NY 10001
In the US: 888.782.9548
US warranty: www.skiphop.com

Patents / Brevets:
www.skiphop.com/patents

IMPORTANT! KEEP FOR FUTURE REFERENCE.

Read all instructions before assembly and use of the Wooden Activity Gym.

CONTENTS:



CLEANING AND CARE:

Wooden Frame: Wipe clean with a slightly damp cloth. Wipe dry before storing.

Playmat: Machine wash cold, gentle cycle. No bleach. Dry flat. Do not iron. Do not dry clean.


Pillow: Machine wash cold, gentle cycle. No bleach. Tumble dry low. Do not iron. Do not dry clean.

All toys: Spot clean only. Do not submerge in water.


WARNING! The toy is to be assembled by an adult. The product contains potentially hazardous small parts in unassembled state. Please keep out of reach of children.

FIRST TIME ASSEMBLY:


Adult assembly required.



Push cross bar into leg, lining up the "D" shapes inside




Secure with a screw.




Repeat on opposite leg.


THREE WAYS TO PLAY:



1. Overhead Play




2. Tummy Time




3. Seated Play

SETUP:


Select mode by lining up center mark with the correct number:




0 - Close for storage



1 - Overhead play



2 - Tummy time




To change mode, grasp each leg at the top of the hub, pull legs away from each other and rotate to desired position. Repeat on opposite side.


Attach toys to cross bar. Adjust heights with hook n loop attachment.

Place mat under Adjustable Wooden Frame lengthwise, so the legs are directly on the floor, not on the mat.

WARNING: Lower position is for tummy time only and not for overhead play.



Correct Tummy Time position



STOP Do not place baby too far under the arch



STOP Do not place baby directly under the arch in Tummy Time mode